


QUICK START GUIDE

FBK30



WHAT'S IN THE BOX



Bluetooth/2.4G
Wireless Keyboard



2.4G Nano
Receiver



USB
Extension Cable



Alkaline
Battery



User
Manual


THE FRONT



THE FLANK / BOTTOM




CONNECTING 2.4G DEVICE




Note: USB extension cable is recommended to connect with Nano receiver. (Make sure the keyboard is closed to the receiver within 30 cm)

CONNECTING BLUETOOTH DEVICE 1 (For Mobile Phone/Tablet/Laptop)



CONNECTING BLUETOOTH DEVICE 2 (For Mobile Phone/Tablet/Laptop)



CONNECTING BLUETOOTH DEVICE 3 (For Mobile Phone/Tablet/Laptop)



OPERATING SYSTEM SWAP



Windows / Android is default system layout.

System	Shortcut [Long-Press for 3S]	Device / Layout Indicator
iOS	+	Light will be off after flashing.
Mac	+	
Windows, Chrome, Android & HarmonyOS	+	

Note: The layout you used last time will be remembered. You can switch the layout by following the above step.

INDICATOR (For Mobile Phone/Tablet/Laptop)



Indicator	Yellow Light	Blue Light	Green Light	Purple Light
Multi-Device Switch	+	+	+	+
Device Switch: Short-Press for 1S	Solid Light 10S	Solid Light 5S		
Pair Device: Long-Press for 3S	No Need to Pair	Pairing: Flashes Slowly Connected: Solid Light 10S		

FN MULTIMEDIA KEY COMBINATION SWITCH



FN Mode: You can lock & unlock FN mode by short pressing FN + ESC by turn.

① Lock Fn Mode: No need to press FN key
② Unlock Fn Mode: FN + ESC

※ After pairing, FN shortcut is locked in FN mode by default,
and the locking FN is memorized when switching and shutting down.

Home Page System Switching Backward Search Input Switching Screen Capture Previous Track Play / Pause Next Track Mute Volume Down Volume Up

Windows / Android / Mac / iOS

OTHER FN SHORTCUTS SWITCH

Shortcuts	Windows	Android	Mac / iOS
+	Pause	Pause	Pause
+	Device Screen Brightness +	Device Screen Brightness +	Device Screen Brightness +
+	Device Screen Brightness -	Device Screen Brightness -	Device Screen Brightness -
+	Screen Lock	Screen Lock	Screen Lock (iOS Only)
+	Scroll Lock	Scroll Lock	

Note: The final function refer to the actual system.

DUAL-FUNCTION KEY



Multi-System Layout

Keyboard Layout	Windows / Android (W / a)	iOS / Mac (ios / mac)
+ + +	Switching Steps: ① Choose iOS layout by pressing FN+I. ② Choose MAC layout by pressing FN+O. ③ Choose Windows / Android layout by pressing FN+P.	
	Ctrl	Control ^
	Start	Option
	Alt	Command
	Alt (Right)	Command
	Ctrl (Right)	Option

LOW BATTERY INDICATOR



Flashing Red light indicates when the battery is below 10%.

SPECIFICATIONS



Model: FBK30
Connection: Bluetooth / 2.4G
Operating Range: 5~10 M
Multi-Device: 4 Devices (Bluetooth x 3, 2.4G x 1)
Layout: Windows | Android | Mac | iOS
Battery: 1 AA Alkaline Battery
Battery Life: Up to 24 Months
Receiver: Nano USB Receiver
Includes: Keyboard, Nano Receiver, 1 AA Alkaline Battery,
USB Extension Cable, User Manual
System Platform: Windows / Mac / iOS / Chrome / Android / Harmony OS...

Q & A

- Question** How to switch layout under different system?
Answer You can switch layout by pressing FN + I / O / P under Windows | Android | Mac | iOS.
- Question** Does the layout can be remembered?
Answer The layout you used last time will be remembered.
- Question** How many devices can be connected?
Answer Interchange and connect up to 4 devices at the same time.
- Question** Does the keyboard remember the connected device?
Answer The device you connected last time will be remembered.
- Question** How can I know the current device is connected or not?
Answer When you turn on your device, the device indicator will be solid.
(disconnected: 5S, connected: 10S)
- Question** How to switch between connected Bluetooth device 1-3?
Answer By pressing FN + Bluetooth shortcut (7 - 9).

WARNING STATEMENT



- The following actions may damage the product.
- To disassemble, bump, crush, or throw into fire is forbidden for the battery.
 - Do not expose under the strong sunlight or high temperature.
 - The discard of battery should obey to the local law, if possible please recycle it.
Do not dispose it as household garbage, because it may cause an explosion.
 - Do not continue to use if severe swelling occurs.
 - Please do not charge the battery.



www.a4tech.com



Scan for E-Manual